

RDXRN50

Installation Instructions

The following processes must be done before using your RDXRN50. **Failure to comply with these processes may void your warranty and make the RDXRN50 inoperable.** Reference the hardware maintenance manual for specific procedural processes.

DO NOT POWER UP THE RDXRN50 UNTIL STEPS 1, 2 AND 3 ARE DONE!!

1. Remove packaging


Referring to Section 1 in the manual, carefully remove the unit from the packing material and set aside all of the accessory components. Using the key, open the unit's door and carefully remove the cardboard insert. Open the insert and remove the print cartridges and media bins. **Retain the cardboard insert with the packing materials so it may be reused in the event the unit needs to be transported.**

2. Install ink cartridges

With the cardboard removed, reference Section 1 of the manual and install the ink cartridges; color on the left, black on the right. NOTE: be careful not to touch the copper colored face of the cartridge.

3. Install the cabling

Reference the illustrations and cabling in Section 1 of the manual to install the cables needed to operate the RDXRN50. Connect the USB cable from a USB port to the Duplicator's USB connection. Connect the Duplicator Power cable as shown in the diagram. Connect the AC Power cable. Connect the provided Ethernet cable between the unit's Ethernet port and the users' Ethernet wall jack.



4. Applying power

The power on sequence is very important! First turn on the AC switch located on the rear just above the power connector. Then push the momentary AC power switch located just above the fan assembly. The LCD panel will illuminate and the unit will go through a setup routine.

5. Finish setup

With the unit powered up and ready, refer to Section 2 of the manual to load the media carrier bins and blank media. Open the front door and wait for the Robotic Disk Transporter to center between the media bin areas. Insert the media bins in the left and right areas, twisting them so they align into place. Place blank media in each bin, keeping the same type of media in the same bin, then close and lock the door. Reference Section 2 of the manual for final networking configuration and setup.

Your RDXRN50 is ready for operation. Rorke Technical Support is available to answer questions or help with these installation instructions. Contact information is below.

ReadMe

